



Recesses are $\frac{3}{4}$ " in diameter $\frac{3}{16}$ " deep centered around the $\frac{1}{4}$ " through hole.

Process:

Drill a small pilot hole, then the recess, then finish the through Hole.