

Use #10 drill bit  
for adjuster hole in center of the block.

